

Reuseable Fitting Installation



First you need to determine the length of hose required and cut to length. We suggest using an abrasive cut off wheel. Then clamp hose in vise with about 1.5" protruding out.



Next thread the shell onto the hose counter clockwise until the hose bottoms out in the fitting.



Next clamp down on the shell with the vise.



Apply some oil to fitting.



Now thread the fitting into the shell clockwise. You do not need to bottom out the fitting. You can leave a couple of threads showing. If install 90 degree fittings on both ends of the hose you will find that you will probably have to clock the fittings.



Job complete!