

BOLT PLACEMENT GUIDE



Steering Gear goes in between the driver's side frame and engine block. The bolts go through the frame to fasten the gear.

